



since 1971
the power to control

Fleischmann
unitro[®]
STÖRMELDESYSTEME

Documentation

FSB 16/16 + FSB16-OUTR -GE-

Blink-Fault Monitoring for medium and high voltage switchgear

**16 fault indications with one or two flashing
frequency in accordance with DIN 19 235**

Function range: 48 / 60 / 110 / 125 / 220V DC

16 freely assignable relay normally open contacts

**2 Common alarm contacts and a horn relay contact output
(change over) with unit-disturbance monitoring
monitoring**



Head office
Gaidorfer Strasse 15
D-71522 Backnang
Telefon : +49 (0)7191 / 141 0
Telefax : +49 (0)7191 / 141 299
E-Mail : info@unitro.de
Internet : http://www.unitro.de

Office Radolfzell
Westendstrasse 3
D-78315 Radolfzell
Telefon : +49 (0)7191 / 141 150
Telefax : +49 (0)7191 / 141 2



since 1971
the power to control

Contents of FSB 16/16 Documentation

Flashing fault annunciator units with signal storage.....	3
Connection diagrams	5
Technical data	6
Programming FSB 16/16 via USB	7
Description FSB 16/16 USB Programmer	7
Dimension drawings.....	13
EMC data sheet	15




since 1971
the power to control

Flashing fault annunciator units with signal storage programmable for front panel installation 16 signal inputs

Types:


FSB 16/16

Flashing fault annunciator
16 signal inputs.



System features front panel mounting module:

- Compact plastic junction housing 96 x 96 x 100mm. Degree of protection: front IP50
- 16 signal inputs with LED-display, red, with exchangeable label strips
- Separate status indicator (green = Power ON)
- Integrated mini horn
- Integrated functional keys + LED-Test
- Supply and signal voltage: 48/60V DC, 110/125V DC, 220VDC
- external horn acknowledge input (acknowledgment voltage as supply voltage)
- Screw terminal plug-in connection max. 2,5mm²
- Rear integrated **mini USB interface** for parameterization each signal: Quiescent / operating current, Running- / fault, response delay variable max. 10min, overall new value / first value.





since 1971
the power to control

System features DIN rail module:


- Din rail housing 200 x 111 x 65mm. Degree of protection IP20
- LED green, Power on (steady light)
- LED yellow (19x relay status) (illuminated when relay contact is closed)
- LED yellow and red for internal data (yellow flashing is intact data transfer / continuous red light at fault)
- 16 Outputs normally open, brought out all poles. Configurable for up to two contact groups with common root contact via integrated jumper
- 2 collective message relay change-over contacts, with disturbed monitoring device. Variety of settings using software programmer are possible.
- 1 horn contact, relay change-over contact. Variety of settings using software programmer are possible.
- Relay contacts max. 24-250V AC / 2A; 110V DC / 0,5A; 220V DC / 0,3A
- Screw terminal plug-in connection max. 2,5mm²




since 1971
the power to control

Connection diagrams

Connection diagram FSB16/16:



Connection diagram FSB16-OUTR:





Technical data

1. **FSB 16:**
control board housing 96 x 96 x 85 + 25mm
(cutting for installation 92 x 92 + 1mm)
FSB 16-OUTR:
snap-on housing 200 x 100 x 60mm
2. **Degree of protection:**
Front IP50, rear IP20, (optional IP54)
DIN rail module: IP20
3. **Weight:**
FSB 16/16 approx. 400g
FSB 16-OUTR approx. 500g
4. **Climatically conditions:**
see page 15
5. **Connection:**
Screw-type terminals/plug in connection
max. 2,5 mm²
6. **Front panel buttons:**
Acknowledge horn
Acknowledge flash light
LED test
7. **Supply voltage:**

48/60V DC	-10% +15%	
110V/125V DC	-10% +15%	
220V DC	-10% +15%	
8. **Max. fuse:**
4 A mtr
9. **Input level for signal inputs:**

48/60V DC	-10% +15%	max. 2,5mA
110/125V DC	-10% +15%	max. 2,5mA
220V DC	-10% +15%	max. 2mA
10. **Minimum fault signal duration:**
DC: 10ms / AC: 100ms
11. **Data retention in the absence of power:**
Flash memory
12. **Power loss 100% ED:**

60V DC	max. 4,5W
110V DC / 220V DC	max. 5,9W
13. **LED-signal:**
FSB 16/16 with marking strips
New value: red flash light
Acknowledge: red steady light
fault removed: LED dark
Power on: green steady light
DIN rail module:
Power on: green steady light
Data LED: yellow flashing
Data Error: red steady light
Relay LEDs: yellow
14. **Flashing frequencies:**
1 / 2 Hz
15. **Relay outputs:**
16 Outputs normally open, Inputs freely assign-
able to outputs for each signal / Standard 1:1)
(configurable to common root contact via inte-
grated jumper).
2 collective message and horn contact, isolated
change-over contact
max. 24-250V AC / 2A
110V DC / 0,5A; 220V DC / 0,3A
16. **Parameterization:**
Mini USB interface per input:
running- / fault
quiescence- / operation current
switch on delay max. 10min
output contacts
overall: first up / new value
17. **Leakage distances and clearances:**
see page 15
18. **EMC, immunity of interference:**
in accordance with EN 61000-4-2,4,5,
see page 15




Programming FSB 16/16 via USB

1. Insert CD.
2. Double-click the file „setup.exe“.
3. The Wizard will guide you through the installation.
4. Connect the USB-cable between PC and FSB (Status-LED flashing with 10Hz).
5. Starting FSB Programmer. If you used the submitted installation path, you will find the FSB Programmer in Start/Programme/UNITRO/FSB-Programmer.
In the same path you also find the documentation (pdf-file).

Discription FSB 16/16 USB Programmer

After starting, you see the flowing view:



Menu bar on top:

Open file:

To load data from PC, open a *.cfg-file with before saved parameters.

Save file:

To save your parameters to PC (*.cfg-file).

Send data to PC:

With a USB connection, you can **load** parameters form the FSB 16/16 to your PC.

Send data to FSB USB:

With a USB connection, you can **send** parameters form your PC to the FSB 16/16.

Print:

Shows a print preview of your parameters.

Info:

Shows the version of FSB 16/16 Programmer and info's to UNITRO-Fleischmann.



since 1971
the power to control

Signal subroutine:

It is possible to activate 3 several signal subroutines.

- First-up signal, single frequency flashing light
- New-value signal, single-frequency flashing light
- New-value signal, two-frequency flashing light

Device name:

To input a 16-character name. This device name will be saved in the device safe, in the absence of power, like all other settings.

Factory Settings:

Makes a reset of all settings in the FSB 16/16 Programmer (such as a reboot of FSB 16/16 Programmer).

Programming via function keys release:

Enable / disable the device programming via the front buttons.

Version:

When you retrieve the device settings on the button "send data to PC", here is the software version of the device.



since 1971
the power to control

Register Card – Signal Inputs:

Card 1 to card 6:

Selection of inputs to be processed.

Card 1 = Input 1-8

Card 2 = Input 9-15 etc.

Clocked inputs:

In pulsed mode, the power loss is reduced to the status inputs by 80%. When signal voltages from 60V DC is recommended to put the inputs in this mode to avoid unnecessary power dissipation (possibly forced cooling equipment). Clocked in, as in the non-clocked operation, an input pulse ≥ 10 ms at DC or AC at ≥ 100 ms, identified as a message.

Relevant/irrelevant:

To activate/deactivate the signal

Closed-circuit current/working current:

Switching between closed-circuit current or working current

Fault indication/operating condition:

Switching between fault indication or operating condition

Register Card – Switch-on delay:

To activate the switch-on delay time



Register Card – Outputs:

Signal inputs	Switch-on delay	Outputs	Outputs inverted	Input to output	Input to group signal output	Labelling
---------------	-----------------	----------------	------------------	-----------------	------------------------------	-----------

Outputs

Invert output card	Group signal output 1
Outputs are not inverted	Parallel to internal horn
Internal horn/Horn output	Group signal output 2
Continuous signal until acknowledgement	Continuous signal as long as signal is activ, alternatively it is not ackn.

Group alarm - closed circuit current

Remarks to the group alarms:
Group alarm (-X9: 13,14,15 u. 16,17,18) - closed circuit current.

Output card setting, plus horn and group signal.

Outputs inverted:

not inverted: As long as a message is present, the corresponding output contact is closed.

inverted: As long as a message is present, the corresponding output contact is opened.

Internal horn:

Wiper signal (40ms): An incoming message activates the horn for 40ms.

Continuous signal until acknowledged: A forthcoming report filed activates the horn. By horn rest button on the device, or an external switch, the horn signal will be acknowledged.

Off horn: horn disabled

Group signal output 1/2:

Output as a wiper (40ms): An incoming message activates the relay contact for 40ms.

Continuous signal until a message is pending, or has not yet been acknowledged: Continuous signal until a message is pending.

As internal horn: for horn parallel function

Group signal output

closed during hibernation:

Enabled:

The group signal output relay is activated during hibernation – power supply failure monitoring

Disabled:

The group signal output relay is closed in working condition.

This setting affects to both group signal relay, if they are not associated with the internal horn



since 1971
the power to control

Register Card – Outputs inverted:

Signal inputs | Switch-on delay | Outputs | **Outputs inverted** | Input to output | Input to group signal output | Labelling

Outputs inverted

- Channel 1 -inverted
- Channel 2 -inverted
- Channel 3 -inverted
- Channel 4 -inverted
- Channel 5 -inverted
- Channel 6 -inverted
- Channel 7 -inverted
- Channel 8 -inverted
- Channel 9 -inverted
- Channel 10 -inverted
- Channel 11 -inverted
- Channel 12 -inverted
- Channel 13 -inverted
- Channel 14 -inverted
- Channel 15 -inverted
- Channel 16 -inverted

Remark: The settings must be enabled in the tab 'Outputs'.

When activated "Outputs inverted" in the Register card „outputs“, the outputs can be specified here to be inverted.

Register Card – In- to Output:

Signal inputs | Switch-on delay | Outputs | Outputs inverted | **Input to output** | Input to group signal output | Labelling

Input to output


Output 1	Output 2	Output 3	Output 4	Output 5	Output 6	Output 7	Output 8
Card 1	Card 1	Card 1	Card 1	Card 1	Card 1	Card 1	Card 1
<input checked="" type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1
<input type="checkbox"/> Input 2	<input checked="" type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2
<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input checked="" type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3
<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input checked="" type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4
<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input checked="" type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5
<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input checked="" type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6
<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input checked="" type="checkbox"/> Input 7	<input type="checkbox"/> Input 7
<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input checked="" type="checkbox"/> Input 8
Output 9	Output 10	Output 11	Output 12	Output 13	Output 14	Output 15	Output 16
Card 2	Card 2	Card 2	Card 2	Card 2	Card 2	Card 2	Card 2
<input checked="" type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1	<input type="checkbox"/> Input 1
<input type="checkbox"/> Input 2	<input checked="" type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2	<input type="checkbox"/> Input 2
<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input checked="" type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3	<input type="checkbox"/> Input 3
<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input checked="" type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4	<input type="checkbox"/> Input 4
<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input checked="" type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5	<input type="checkbox"/> Input 5
<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input checked="" type="checkbox"/> Input 6	<input type="checkbox"/> Input 6	<input type="checkbox"/> Input 6
<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input type="checkbox"/> Input 7	<input checked="" type="checkbox"/> Input 7	<input type="checkbox"/> Input 7
<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input type="checkbox"/> Input 8	<input checked="" type="checkbox"/> Input 8

When activated “In- to Output” in the Register card “outputs“, the input-output mappings can be made.




since 1971
the power to control

Register Card – Input to group signal outputs:



The selected inputs set the corresponding group alarm output.

Register Card – labeling:




On the input screen message 1 to message 16 and a suitable text size, the labeling strips can be filled or processed.

Attention: Only after pushing the button „Send data to FSB usb“ the settings in the FSB 16/16 Programmer are send to the device!



since 1971
the power to control

Dimension drawing FSB16-OUTR:



Verwendungsbereich		Zul. Abweichung		Oberfläche		Maßstab		Gewicht	
01	H-GA1+GA2	10.11.11	KFIR						
Zust.	Änderung	Datum	Nach	Urspr.	Ers. f.:	7	Ers. d.:	8	Blatt
								FSB 16OUTR	
								Zeichnungsnummer	



since 1971
the power to control

Information on applied guidelines and standards

EU	Guidelines
2004/108/EG	EMC guideline (electromagnetic compatibility)
2006/95/EG	Low voltage directive (LVD)

	Product standards
EN 50178:1997	Equipping power installations with electronic equipment
EN 61010-1:2001	Safety requirements for electrical equipment for measurement, control and laboratory equipment. Part 1: general requirements
EN 61131-2:2007	Programmable logic controllers. Part 2: equipment requirements and tests

	EMC
EN 61000-6-2:2005	EMC Part 6-2 generic standards - Immunity for industrial environments
EN 61000-6-4:2007	EMC Part 6-4 generic standards - Emission standard for industrial environments
EN 61326-1:2006	EMC - requirements Electrical equipment for measurement, control and laboratory use

Immunity levels to:	EN 61000-4-2 (ESD)	Severity 3
	EN 61000-4-4 (Burst)	Severity 3
	EN 61000-4-5 (Surge)	Severity 3
	EN 61000-4-6 (HF-line bound)	Severity 3

Safety and environmental requirements to EN 50178

Climatic conditions:	Class 3K3 Ambient and operating temperature: -20° to +65°C 4% to 85% relative humidity not condensing Class 1K4 Storage temperature: -25° bis +55°C Class 2K3 Transport temperature: -25° bis +70°C
Minimum creepage distances:	Pollution degree 2 250V eff, 1mm
Insulation test:	325V: 1,1KV eff.

For further processing of non-self equipment (components) The applicable installation regulations must be observed. When installing equipment in addition is the appropriate instrument provision. Standards at the time of printing.