# Belzona 1391



FN10032 (CERAMIC HT)

## INSTRUCTIONS FOR USE

- 1. TO ENSURE AN EFFECTIVE MOLECULAR WELD
- **METALLIC SURFACES APPLY ONLY TO BLAST** i) CLEANED SURFACES
- Brush away loose contamination and degrease with a rag soaked in a) Belzona® 9111 (Cleaner/Degreaser) or any other effective cleaner which does not leave a residue e.g. methyl ethyl ketone (MEK).
- Select an abrasive to give the necessary standard of cleanliness b) and a minimum depth of profile of 3 mils (75 microns). Use only an angular abrasive.
- Blast clean the metal surface to achieve the following standard of c) cleanliness:
  - ISO 8501-1 Sa 21/2 very thorough blast cleaning. American Standard near white finish SSPC SP 10. Swedish Standard Sa 21/2 SIS 05 5900.
- After blasting, metal surfaces should be coated before any d) oxidation of the surface takes place.

#### SALT CONTAMINATED SURFACES

Metal surfaces that have been immersed for any periods in salt solutions e.g. sea water, should be blasted to the required standard, left 24 hours to allow any ingrained salts to sweat to the surface and then washed prior to a further brush blast to remove these. This process may need to be repeated to ensure complete removal of salts. The soluble salt contamination of the prepared substrate, immediately prior to application, should be less than 20mgs/m<sup>2</sup>.

- SURFACES ALREADY REBUILT WITH BELZONA<sup>®</sup> 1111, BELZONA<sup>®</sup> 1311 OR BELZONA<sup>®</sup> 1511 Allow the Belzona<sup>®</sup> 1111 or Belzona<sup>®</sup> 1311 to cure for at least 2 hours and Belzona<sup>®</sup> 1511 to cure for at least 6 hours. ii)
- a)
- Grit blast to create a frosted surface free from any gloss with a b) target profile of 40 microns.
- Remove debris and degrease with Belzona® 9111 or any other c) effective cleaner which does not leave a residue e.g. MEK.

#### **COMBINING THE REACTIVE COMPONENTS** 2.

- If product has been stored below 10°C (50°F), warm the sealed a) Solidifier unit carefully to 60°C (140°F), shake and allow to cool before use.
- Transfer the entire contents of the Solidifier can into the Base b) module. Mix thoroughly together to achieve a uniform material free of any streakiness.

#### NOTES:

#### 1. APPLICATION TEMPERATURE

Belzona<sup>®</sup> 1391 should NOT be applied at temperatures below 50°F (10°C).

#### WORKING LIFE

From the commencement of mixing, Belzona® 1391 must be used within the times shown below.

Temperature	50°F	68°F	77°F	85°F	105°F
	(10°C)	(20°C)	(25°C)	(30°C)	(40°C)
Use all material within	80 mins.	40 mins.	30 mins.	20 mins.	10 mins.

#### 3. MIXING SMALL QUANTITIES

For mixing small quantities of **Belzona® 1391** use: 5 parts Base to 1 part Solidifier by volume 13 parts Base to 1 part Solidifier by weight.

#### 4. VOLUME CAPACITY OF MIXED BELZONA® 1391

26.1 cu in (431 cm<sup>3</sup>) per kg.

#### 3. APPLYING BELZONA® 1391

#### FOR BEST RESULTS Do not apply when:

- The temperature is below 50°F (10°C) or the relative humidity is i) above 90%.
- ii) The substrate temperature is less than 5°F (3°C) above dewpoint.
- Rain, snow, fog or mist is present. iii)
- iv) There is moisture on the metal surface or is likely to be deposited by subsequent condensation.
- The working environment is likely to be contaminated by oil/grease v) from adjacent equipment or smoke from kerosene heaters or tobacco smoking.

#### (A) FOR SERVICE TEMPERATURES BELOW 212°F (100°C) BELZONA® 1391 IS APPLIED AS A SINGLE COAT SYSTEM AT 24-30 MILS.

Apply the Belzona® 1391 directly on to the prepared surface with a stiff bristled brush or with the plastic applicator provided. To achieve the correct film thickness of 24-30 mils (600-750 microns), a practical coverage rate of 5.6 sq. ft (0.52 m<sup>2</sup>) per kg unit should be obtained.

#### TO ACHIEVE A UNIFORM COATING

- Apply the coating in one operation without interruption. a)
- In the area being treated by one unit of material, first "stripe coat" b) detail areas such as brackets, edges, corners and welds. Use a brush or applicator to initially wet out the substrate before building up to the full coating thickness over the complete area designated for that unit of material.
- Use a wet film thickness gauge to regularly check that the correct c) film thickness is being achieved.
- Finish application with a brush to obtain uniform coverage. d)
- Ensure adequate lighting is available to prevent misses. e)

#### INSPECTION

- Immediately after application of each unit, visually inspect for a) pinholes and misses. Where detected these should be immediately brushed out.
- b) Once the application is complete and the coating has hardened, carry out a thorough visual inspection to confirm freedom from pinholes and misses, and to identify any possible mechanical damage.
- Where wet sponge testing is being used as an aid to confirm c) continuity of the coating, care should be taken to ensure that the surface is thoroughly wetted out by repeated passage of the sponge tester over the surface. The addition of a wetting agent such as detergent to the water used on the sponge will also assist. Under no circumstances should high voltage spark testing be used.

#### www.belzona.com

#### (B) FOR SERVICE TEMPERATURES OF 212-248°F (100-120°C) BELZONA<sup>®</sup> 1391 IS APPLIED AT 32-40 MILS.

Where application conditions permit, **Belzona**<sup>®</sup> **1391** should be applied as a single coat as in (A) above, but at a thickness of 32-40 mils (800-1000 microns). To achieve the correct film thickness, a practical coverage rate of 4.2 sq. ft (0.39 sq. m) per kg unit should be obtained. Where it is not possible to achieve a uniform coating at this thickness, the material should be applied as a two coat system.

- the material should be applied as a two coat system.
  a) Apply the first coat of **Belzona<sup>®</sup> 1391** as in (A) above and allow to harden for at least 16 hours.
- b) Before carrying out repairs or applying a second coat, wash the surface of the **Belzona<sup>®</sup> 1391** with a warm detergent solution to remove any amine bloom that has formed. Rinse with clean water and allow to dry.
- c) Grit blast to create a frosted surface free from any gloss with a target profile of 40 microns. Remove debris and degrease with Belzona<sup>®</sup> 9111 or any other effective cleaner which does not leave a residue e.g. MEK.
- Apply a second coat of Belzona<sup>®</sup> 1391 at a thickness of 12-15 mils (300-375 microns). To achieve the correct film thickness, a practical coverage rate of 11 ft<sup>2</sup> (1 m<sup>2</sup>) per kg unit should be obtained.
   Belzona<sup>®</sup> 1391 is available in blue and gray, to facilitate application and to prevent misses. In service the colour of the applied product may change.

#### REPAIRS

Any misses, pinholes or mechanical damage found in the coating should be repaired by grit blasting to produce a frosted appearance with a target profile of 1.5 mil (40 microns) prior to application of further material as detailed above.

#### COLOR

**Belzona® 1391** is available in blue and gray to facilitate application and to prevent misses. These colors are for identification only and there will be some variation between batches. In service the color of the applied product may change.

#### CLEANING

Mixing tools should be cleaned immediately after use with **Belzona® 9111** or any other effective solvent e.g. Methyl ethyl ketone (MEK). Brushes, injection guns, spray equipment and any other application tools should be cleaned using a suitable solvent such as **Belzona® 9121**, MEK, acetone or cellulose thinners.

#### 4. COMPLETION OF THE MOLECULAR REACTION

Allow **Belzona<sup>®</sup> 1391** to solidify as below subjecting it to the conditions indicated.

Substrate temperature	Use involving no loading	Light loading	Cold water immersion	Hot water immersion*
50°F/10°C	8 hours	16 hours	7 days	14 days
68°F/20°C	51/2 hours	9 hours	4 days	7 day
77°F/25°C	31/2 hours	4½ hours	2½ days	4 days
85°F/30°C	2 hours	3 hours	2 days	3 days
105°F/40°C	1½ hours	2 hours	1½ days	2 days

\* In certain instances it may be advantageous to post cure material prior to putting into service where chemical contact is involved. Refer to Belzona<sup>®</sup> TKL for specific recommendations.

### 5. FINAL SOLIDIFICATION OF BELZONA® 1391

When time is important and equipment usage is pressing, then by installing forced air heaters and taking steps to contain this heat around the equipment being reclaimed, final solidification time can be as little as 24 hours. Due allowance must be made for "warming up".

A final physical check can be made as precaution by taking a metal object and tapping the surface of the **Belzona® 1391**. Any partially solidified or soft spots will give a dull tone in relation to the metallic tone offered by solidified **Belzona® 1391**.

If there is any doubt regarding final solidification then **BE SAFE - MAKE MORE TIME.** 

#### 6. POST CURING TO OBTAIN OPTIMUM HEAT RESISTANCE

Although the heat resistance of **Belzona<sup>®</sup> 1391** cured at normal ambient temperatures is good, this can be improved dramatically by elevating the cure temperature.

This can be done prior to putting coated equipment into service by first allowing the coating to harden at ambient temperature for 24 hours prior to force curing at 212°F (100°C) for between 2 hours and 24 hours. This procedure should be adopted for any application when immediate exposure to a hot aggressive environment will occur.

Alternatively, the coating can be allowed to harden at ambient temperature for the time indicated in the "hot water immersion" column of the "Completion of the molecular reaction" table (see Section 4) and then put into service when any heat involved will advance the cure and enhance the heat resistance. This procedure is suitable for application where operating temperatures will be achieved gradually.

#### 7. STORAGE

**Belzona<sup>®</sup> 1391** Solidifier may crystallize on prolonged storage and particularly if stored at temperatures below 10°C (50°F). It is recommended that the sealed unit of Solidifier is carefully warmed to 60°C (140°F), shaken and allowed to cool before use.

#### **HEALTH & SAFETY INFORMATION**

Please read and make sure you understand the relevant Material Safety Data Sheets.

The technical data contained herein is based on the results of long term tests carried out in our laboratories and to the best of our knowledge is true and accurate on the date of publication. It is however subject to change without prior notice and the user should contact Belzona to verify the technical data is correct before specifying or ordering. No guarantee of accuracy is given or implied. We assume no responsibility for rates of coverage, performance or injury resulting from use. Liability, if any, is limited to the replacement of products. No other warranty or guarantee of any kind is made by Belzona, express or implied, whether statutory, by operation of law or otherwise, including merchantability or fitness for a particular purpose.

Nothing in the foregoing statement shall exclude or limit any liability of Belzona to the extent such liability cannot by law be excluded or limited.

Copyright © 2013 Belzona International Limited. Belzona® is a registered trademark.



ISO 9001:2008 Q 09335 ISO 14001:2004 EMS 509612

Manufactured under an ISO 9000 Registered Quality Management System



Belzona 1391 - Instructions for Use - (2)

www.belzona.com

Printed in England Publication No. 08-04-13